



MOUNTING INSTRUCTIONS FOR ELS-285

1. Set right side hard case saddlebag with outside facing up on strong working surface. Measure $\frac{1}{2}$ " in from lower right hand corner of recessed name window (fig 1). Draw an erasable line from this point perpendicular to the bottom of the bag.
2. Place ELS-285 mounting plate (with lock mechanism to right) on the bag (fig 2). Align the right hand edge of the ELS-285 mount flange on the line. Move the ELS-285 so the bottom right mount hole is centered 1" up from the bottom of the bag. Making sure the bottom left hole is also 1" from the bottom of the bag, mark 1 hole.
3. Using an 11/32" drill, drill the hole you have marked. Insert a bolt provided to secure this point. Double-check the alignment along the bottom and the line you have drawn and mark and drill the remaining 3 holes.
4. Place the ELS-285 inside the hard case. With the lock toward the rear of the case, align all four holes of the mounting plate with the holes you drilled. Slip gasketed seal washers on all 4 bolts and insert from the outside of the case. Tighten lock nuts.